

911 Call Dialer Model HQ-TS-38

Installation & Programming Instructions

Installation:

Follow these steps as shown in the figure below:

IMPORTANT: RJ11 jacks are reversible e.g. the LINE and the PHONE can be plugged on either one.

1. Plug one socket of the unit to the PSTN (CO) telephone
2. Plug the other socket of the unit to the telephone handset or system.

Local Programming:

Using the dial-pad of a handset connected to the 'PHONE' socket of the dialer, dial these numbers:

Step 1) Enter **# 0 *** (you should hear a 'Beep' sound) -- entering the programming mode

Step 2) Enter **01** (you should hear a 'Beep' sound) -- entering function code to restrict numbers

Step 3) Enter **NUMBER** (this is the phone number that will be dialed automatically every time you take the phone off hook e.g. 911, 411, 305-512-1212, etc)

Step 4) Hang-up or press **##** -- exit

Remote programming:

You may also program this auto dialer remotely by calling it in from another phone e.g. cell phone. To do this, you will need someone to answer the call at the receiving end where the auto dialer is installed. Simply call it, wait 2 rings to answer the call using the phone connected to the auto dialer, and follow steps 1-3 above using the keypad of the calling phone e.g. your cell phone.

Reset Instructions:

To reset the Call Restrictor, follow these steps:

Step 1) Enter **# 0 *** (you should hear a 'Beep' sound) -- entering the programming mode

Step 2) Enter **88** (you should hear a 'Beep' sound) -- reset code

Step 3) Enter **##** (exit)

Please visit hqtelecom.com for additional support on this product.