

Bluetooth Speaker RockDoc/PITTBULL Model ROCK05BT

Instructions Manual

(revised by hqtelecom.com)



Bluetooth Speaker Specifications:

- Dimensions: 3" x 2" x 2" (75mm x 50mm x 53mm)
- Frequency response: 150-18000 HZ (± 3 dB)
- Speaker Output: RMS 6W (3W+3W), 4 Ohms
- 3.7V Lithium Battery (model BL-5B, factory installed) can play music and charge simultaneously while connected to power source
- Line In/5v: Micro USB power supply, audio input
- OFF/ON: On-Off switch setting
- Micro SD: Slot for Micro SD card

Packaging Includes:

- Bluetooth Speaker with built-in Micro SD slot and speakers (2 x 3W)
- Multi-purpose Cable: Side 1: Audio 3.5mm jack (Line In) & micro USB (power purpose) | Side 2: Standard USB plug
- Instructions manual

Charging the battery on the RockDoc® Speaker



Your RockDoc® Speaker comes from the factory equipped with a 3.7V Lithium battery (model BL-5B).

- This battery is installed in the battery compartment located in the bottom of the RockDoc® Speaker.
- To charge the battery, connect the multi-purpose cable on Micro USB LINE IN DC-5V socket on your RockDoc® Speaker, and the other end (USB plug) on a PC, laptop, etc. You can also connect the USB plug into a AC/DC power adapter 5V, 1A (not included).
- The LED light on the RockDoc® Speaker will indicate the following:
 - When RockDoc® is turned ON, the LED light is BLUE.
 - When charging and RockDoc® is turned OFF, light is RED.
 - When charging and RockDoc® is turned ON, light is PINK.
 - When charging is complete, RED light turns OFF.

Note: The first time you are charging the battery, it may take up to 8 hours to fully charge.

Pairing your Bluetooth device with the RockDoc® Speaker

You can pair the RockDoc® speaker with most Bluetooth-enabled devices (such as smartphones, PCs, tablets, PDAs, and many others). Once your RockDoc® speaker is paired with a Bluetooth-enabled device, you can play music on your Bluetooth-enabled device and listen on the RockDoc® speaker.

- Turn the RockDoc® speaker “ON” (Note: You must remove your MicroSD memory card, if installed).
- Press the “MODE” button twice (a “chime” sound will be heard)

- Turn Bluetooth “ON” on your Bluetooth-enabled device and/or start searching for Bluetooth devices.
- Look for “RockDoc” in the Bluetooth-enabled devices list. You may have to refresh the list.
- Select “RockDoc” to pair your device and the speaker. You may need to enter the code “0000”. Pairing should complete after selecting RockDoc and/or entering code.
- Now just play music through your Bluetooth-enabled device as you normally would and music will play through your RockDoc® speaker.

Using the Micro SD/TF Slot:



- When using the Micro SD/TF slot you must insert a Micro SD memory card (not included) with pre-loaded MP3 formatted songs.
- The Micro SD/TF slot can hold up to 64GB Micro SD memory cards.
- The Micro SD memory card will only insert in one way, connectors must be facing up, and it will click into place when fully inserted.
- There is no internal memory available on the RockDoc® device.

Using the Buttons on the RockDoc® Speaker:



- MODE: Pressing the “MODE” button will toggle between Line In, Micro SD, and Bluetooth.
 - ▶||/■ Play/Pause/Stop song in progress
 - VOL: Toggle between volume and song selection
 - ◀◀/V- : Previous Song/Rewind/Volume Down
 - V+/ ▶▶ : Next Song/Fast Forward/Volume Up
 - The default mode is Line In. If you insert a Micro SD memory card, it will automatically begin to play music.
 - To change volume first click and release the VOL button. Next, press ◀◀ /V- for volume down, or V+/ ▶▶ for volume up. In order to change back to song selection, click and release the VOL button again.
 - To change the song simply click and release the ◀◀/V- for previous song or V+/ ▶▶ for next song
- How to pair your Bluetooth device with the RockDoc®

For more information or support on your RockDoc® [Bluetooth speaker](#), please visit us at <https://hqtelecom.com>